FORD

RANGER PX 2011 TO 20189

FRONT	DIESEL ENGINE			7
Estimated Lift: 50mm	PART NUMBER	QTY	UNIT PRICE \$	8
SPRING: No Bar	2997	1		
STRUT SPORT	90019 1	2		
SPRING: Bar	2998	1		
STRUT SPORT	*90020 / <mark>90019</mark> 1	2		9
SPRING: Bar / Winch	2999	1		
STRUT SPORT	90020 1	2		
SPRING: No Bar: 30mm LIFT	3048	1		
STRUT SPORT	90019 1	2		
BP-51 SELECTION: Estimated Li	ft: 30 - 40mm			
BP-51 COIL OVER FRONT RH	BP5190005R			
BP-51 COIL OVER FRONT LH	BP5190005L	1		
BP FIT KIT FRONT	VM80010011			
TRIM PACKER	FK56 2			
UPPER STRUT BUSHES	OME3135 1	<u>_</u>		
STRUT TOP HAT KIT	OMETH006 7	2		
REAR	ALL MODELS			
Estimated Lift: 50mm	PART NUMBER	QTY	UNIT PRICE \$	
SPRING: MEDIUM LOAD	EL102R 4	0		
NITROCHARGER SPORT	*60101 / 60023	2		
SPRING: CONSTANT 300 KGS	EL103R 4	0		
NITROCHARGER SPORT	*60102 / <mark>60101</mark>	2		
SPRING: CONSTANT 600 KGS	EL104R 4	0		
NITROCHARGER SPORT	60102	2		
BP-51 SELECTION				
BP-51 SHOCK REAR RH	*BP5160037R / BP5160027R			
BP-51 SHOCK REAR LH	*BP5160037L / BP5160027L	1		
BP-51 SHOCK REAR LH BP FIT KIT REAR		1		
	BP5160027L			
BP FIT KIT REAR	BP5160027L VM80010012	1		
BP FIT KIT REAR GREASABLE SHACKLE KIT	BP5160027L VM80010012 OMEGS20			
BP FIT KIT REAR GREASABLE SHACKLE KIT GREASABLE PIN KIT	BP5160027L VM80010012 OMEGS20 OMEGP10 OMESB117	1		
BP FIT KIT REAR GREASABLE SHACKLE KIT GREASABLE PIN KIT SPRING BUSH KIT	BP5160027L VM80010012 OMEGS20 OMEGP10 OMESB117 OMESB118 OMEU66 4 OMEU66A	1		

REMARKS:

1 No top mounting bushes supplied, use OME3135. OE bushes may be re-used if in good condition.

2 Trim Packer FK56 provides 10mm lift at the wheel.

3 OMESB117 suits OE Shackle.

OMESB118 Bush Kit suits OME Greasable Shackle OMEGS20.

Use OMEU66 when fitting EL102R.
Use OMEU66A when fitting EL103R and EL104R.
Use OMEU66B when fitting EL104R with EL34XL.

5 Fitment of Driveline Spacer Kit FK57 is recommended to re-align driveline.

6 EL34XL will give approximately 30mm extra lift or increase loading capacity at design height by approximately 300kg.

Strut Top Hat Kit may be required if original equipment is worn.

If a TAD110 Frontier tank is installed in the vehicle, when fitting the FK57 spacer kit, the tank will need to be lowered to allow removal of the centre bearing bolts.

Important: Please refer to TSB003.