

Self-Recovery Winch

Model: DV-9

PN: 856329 12V 856345 12V 856322 12V 931781 12V

856355 24V 931787 24V

Introduction

▶ Feature

Line pull: 4,082 kg / 9,000 lb wire rope first layer

Wire rope: 8.3 mm \times 30.5 m (21/64" \times 100') galvanized aircraft A7 \times 19

Brake: Patented cone brake holds full load

Clutch: Turn the T-handle for rapid wire rope payout

Control: Handheld pendant switch to power the winch

▶ Unpacking

Winch assembly	1 pc
Control box	1 pc
Remote control	1 pc
Wire rope with hook	1 рс
· Roller fairlead	1 pc
• 1.8 m (6') 2 gauge battery lead	1 pc

► Read this manual carefully


You should carefully read and understand this manual before operating it. Careless winch operation may result in personal injury hazards or property damage.

<u>Installation</u>

Before using the winch, make sure all electrical components have no corrosion or damaged; the environment should be clear and dry.

▶ Winch and roller fairlead mountings


- It is very important that the winch will be mounted on a flat and hard surface of mounting channel in order to make sure the motor, drum and gearbox housing are aligned correctly.
- Roller fairlead does not mount to the winch directly.
- · The wire rope shall be wound in an under-wound orientation only.



 Two (2) M12 x 1.75 pitch 8.8 grade with 76 N-m torque settings (maximum) high tensile steel bolts must be used for fastening the roller fairlead into the mounting channel.


▶ Wiring Diagram

Attach the black lead firmly to the negative (–) battery terminal and red lead to the positive (+) battery terminal. The voltage drop for the winch motor must not exceed 10% of the nominal voltage of 12/24V DC.



▶ Nut fastening for motor & contactor

- 1. Holding the lower nut on the stub and fastening the upper nut clockwise.
- 2. The torque setting for nut is 14 N-m/124 lb-in.



Warning

- The winch is not intended to be used in any manner for the movement or lifting of personnel.
- The rated line pull shown is based on the first layer of rope on the drum.
- The rope winding on the drum shall remain 5 wraps from the drum.

Parts List

Item No.	Description	Part No.	Qty
1	Motor 12V	882153	1
	Motor 24V	883126	1 '
2	Tie bar kit	880003	2
	Tie bar kit for PN:856345	882546	2
3	Motor support rack	881779	1
4	Motor coupling	880005	1
5	Drum bushing	880006	2
6	Drum kit	881101	1
7	Gearbox support rack	881780	1
8	Grounding lead	880009	1
9	Wire rope w/hook	880010	1
10	1 st shaft	880011	1
11	3 rd ring gear kit	881781	1
12	3 rd stage carrier	880013	1
13	3 rd bushing	880014	1
14	2 nd stage carrier	880015	1
15	1 st stage carrier	880016	1
16	1 st & 2 nd ring gear	880017	1
17	1 st pinion kit	880018	1
18	Clutch kit	881303	1
19	Gear box kit	881782	1
20	Cone brake disc kit	880021	1
21	Brake cover kit	881783	1
22	Roller fairlead	880023	1
23	Mounting hardware	880024	1
24	Remote control	880126	1
25	Handsaver strap	880026	1
26	Control box 12V	881164	1
	Control box 24V	881165	
26-1	Remote socket kit 12V	881373	1
	Remote socket kit 24V	881374] '
26-2	Control pack 12V	881400	1
	Control pack 24V	881401	ן ' ו
27	Brake clutch base	881100	1

Winch Assembly

