




1 FIT DRAW DIVIDER

You will need:

3 mm Hex Key

8 mm Flat Wrench

- (A) Slide the Slotted Divider Plate into Solid Divider Plate. Adjust the two Plates to the approximate width of the Draw and loosely fasten the two plates together using two of the M5 x10 Button Head Bolts, two M5 Flat Washers and two M5 Nyloc Nuts supplied. The Flat Washers and Nyloc Nuts go on the side of the Slotted Plate.



- (B) Open the Draw and place the Divider Plates into the Draw with the Slotted Plate to the rear. Line the Divider Plates up with Hole Sets 1 or 2 as indicated. Slide the Divider Plates apart, up against the sides of the Draw.

Secure the Divider Plates to the Draw using four M5 x10 Button Head Bolts, four M5 Flat Washers and four M5 Nyloc Nuts as shown. The Nyloc Nuts and Flat Washers must go to the inside of the Draw.

Tighten the middle bolts from Step 1A and place the Plastic Nut Caps supplied over the Nyloc nuts.

